



IN-City Single Pod assembly

- 1. After removing all pieces from the sheet with a hobby/utility blade, attach faceplates onto sides with superglue. Make sure to line the plates up before you glue to make sure you have the correct pieces matched up.**
- 2. Slide faces together at the corners and glue the top and bottom into the interlocking notches.**
- 3. Prime with flat enamel spraypaint for best results.**